

Assembly Instructions

Universal Decoy Pole

(UDP-4812)

Thank you for purchasing the Universal Decoy Pole. The pole adjusts to the length of four feet, eight feet and twelve feet. Use as necessary. Parts included fit popular decoy styles.

Durable steel pole construction with integrated foot pegs ensure secure anchoring. Easy to use quick clips lock the pole sections together for easy adjusting. Cables attach the quick clips to the pole to prevent loss.

Package Contents




- ❑ Part A: (1) 1" x 47" round tube
- ❑ Part B: (1) 3/4" x 47" round tube with foot peg
- ❑ Part C: (1) 3/4" x 47" round tube with foot peg and crimped bottom end
- ❑ Part D: (1) 1" x 7" round tube with square end
- ❑ Part E: (1) 3/4" x 5 3/4" round tube with (2) holes
- ❑ Part F: (4) 1/4" quick clips

Assembly

Assembly can be done in a 4' length, 8' length and 12' length.


1. Four foot pole assembly.

- a. Connect part C (3/4" x 47" round tube with foot peg and crimped bottom end) to part D (1" x 7" round tube with square end) or use alone depending on your decoy style.
- b. Align the holes in the pole sections and secure together with the quick clips.



2. Eight foot pole assembly.

- ▶ **Start with assembly for Decoy Style A.**
 - a. **Connect part C** ($3/4"$ x $47"$ round tube with foot peg and crimped bottom end) **to part A** ($1"$ x $47"$ round tube). **Align the holes in the pole sections and secure together with the quick clips.**
 - b. **Connect part E** ($3/4"$ x $5\ 3/4"$ round tube) **into the other end of part A** ($1"$ x $47"$ round tube). **Align the first hole in the pole sections and secure together with the quick clips.**
- ▶ **Continue building for Decoy Style B.**
 - c. **Connect part D** ($1"$ x $7"$ round tube with square end) **over the exposed end of part E** ($3/4"$ x $5\ 3/4"$ round tube with (2) holes). **Align the holes in the pole sections and secure together with the quick clips.**



3. Twelve foot pole assembly.

- ▶ **Start with assembly for Decoy Style A.**
 - a. **Connect part C** ($3/4"$ x $47"$ round tube with foot peg and crimped bottom end) **to part A** ($1"$ x $47"$ round tube). **Align the holes in the pole sections and secure together with the quick clips.**
 - b. **Connect part B** ($3/4"$ x $47"$ round tube with foot peg) **to the exposed end of part A** ($1"$ x $47"$ round tube). **Make sure the foot peg is farthest from part A.** **Align the holes in the pole sections and secure together with the quick clips.**
- ▶ **Continue building for Decoy Style B.**
 - c. **Connect part D** ($1"$ x $7"$ round tube with square end) **into the other end of part B** ($3/4"$ x $47"$ round tube with foot peg). **Align the first hole in the pole sections and secure together with the quick clips.**

